

### Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and Modbus funtionality. For monitoring over-, under or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts or fire and smoke control dampers. Options available with LCD display. NEMA 4X / IP65 rated enclosure.

# Technical data sheet







5-year warranty





## **Type Overview**

**Technical data** 

Туре	Measuring range pressure [Pa]	Measuring range pressure [inch WC]	Communication	Output signal active pressure	Output signal active volumetric flow	Burst pressure	Display type
22ADP-554	-1002500	-0.410	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	-
22ADP-554L	-1002500	-0.410	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD

Electrical Data	Nominal voltage	AC/DC 24 V
	Nominal voltage range	AC 1929 V / DC 1535 V
	Power consumption AC	4.3 VA
	Power consumption DC	2.3 W
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm²
	Cable entry	Cable gland with strain relief 2x ø6 mm (1/2" NPT conduit adapter included)
Data bus communication	Communication	Modbus RTU
	Number of nodes	Modbus see interface description
Functional Data	Sensor Technology	piezo measuring element
	Application	air
	Multirange	8 measuring ranges selectable
	Voltage output	2 x 05 V, 010 V, min. resistance 10 kΩ
	Output signal active note	Output 05/10 V selectable with switch
	Display	LCD, 1.14x1.38 in. [29x35 mm]

# Measuring Data

Response time	adjustable 0.8 s or 4.0 s
Measured values	Differential pressure Volumetric flow
Measuring fluid	air and non-aggressive gases

With backlight

(parametrisable)

Measured values: Pa, inch WC (programmable) Measured values volumetric flow: m³/h, cfm



	Technical data sheet			22ADP	-554
Measuring Data	Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting
		S0	02500	010	<b>*</b>
		<b>S</b> 1	02000	08	
		S2	01500	06	
		S3	01000	04	
		S4	0500	02	
		S5 S6	0250 0100	01 00.4	
		50 S7	-100100	-0.40.4	
	Measuring range volumetric flow		ole via Modbu		
	3 3	Default setting: 0750'000 cfm			
		Selectab	ole units: m³/l	n, m³/s, cfm	
	Accuracy pressure			inch WC: ±0.02 inc	
				inch WC: ±0.04 inc	h WC
	Long-term stability	±2.5% F	SO (Full Scale	Output) / 4 yr.	
Materials	Cable gland	PA6, bla	ck		
	Housing	Cover: PC, orange			
			PC, orange		
			R70, black		
		UV resis	tant		
Safety Data	Protection class IEC/EN	III, Safe	ty Extra-Low \	/oltage (SELV)	
	Power source UL	Class 2 S	Supply		
	Degree of protection IEC/EN	IP65			
	Degree of protection NEMA/UL	NEMA 4	Х		
	Enclosure	UL Enclo	sure Type 4X		
	EU Conformity	CE Mark			
	Certification IEC/EN	IEC/EN (	50730-1 and I	EC/EN 60730-2-6	
	Quality Standard	ISO 900	1		
	UL Approval	cULus a E60730-		0-1A/-2-6, CAN/CS	A
	Type of action	Type 1			
	Rated impulse voltage supply	0.8 kV			
	Installation method	Indeper	Independently mounted control		
	Pollution degree	3			
	Ambient humidity	Max. 95	% RH, non-co	ndensing	
	Ambient temperature	-1050°	°C [15122°F	]	
	Fluid temperature	-1050°	°C [15122°F	]	
	Storage temperature	-4176°	°F [-2080°C]		

## **Safety Notes**



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



#### Remarks

#### Manual zero-point calibration

In normal operation zero-point calibration should be executed every 12 months.


Attention! For executing zero-point calibration the power supply must be connected one hour before.

- Release both connection tubes from the pressure terminals + and -
- Press the button until the LED lights permanently
- Wait until the LED flashes again and reinstall the connection tubes to the pressure ports (note
- + and -)

### **Indicators and Operation**

#### **Indicators**

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- 1 Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- 4 Radio active (not available)
- Status bar
- 6 Measured value (\* appears when TLF function is activated for this value)
- Unit of measure
- 8 Measured value

## Parts included

Parts included	Description	Туре	
	Mounting plate L housing	A-22D-A10	
	Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22AP-A08	
	Cable Gland with strain relief ø68 mm Dowels		
	Screws		
	1/2" NPT conduit adapter, 2x ø6 mm		

## Accessories

Optional accessories	Description	Туре
	Pitot tube, Metal, L 1.5", Tube connection 0.2"	A-22AP-A01
	Pitot tube, Metal, L 4", Tube connection 0.2"	A-22AP-A03
Tools	Description	Туре
	Belimo Duct Sensor Assistant App	Belimo Duct
		Sensor Assistant
		Арр
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
	* Bluetooth dongle A-22G-A05	

Certified and available in North America, European Union, EFTA States and UK.



### Service

#### **Tools connection**

This sensor can be operated and parametrized using the Belimo Assistant App.

When using the Belimo Duct Sensor Assistant App, the Bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For the standard operation and parametrization of the sensor the Bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

#### Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

#### Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrization in the Belimo Assistant App



### Wiring Diagram

Notes Si


Supply from isolating transformer.



The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination.

Modbus-GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.





① Button ② red: Error ③ yellow: Tx ④ yellow: Rx ⑤ and ⑥ Status LED \* Factory setting P Pressure unit T Response time U Output signal

#### **Detailed documentation**

The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination)

In addition to the information on the bus, the following analog outputs are available:


AOU1: differential pressure

AOU2: volumetric flow

The volumetric flow is calculated from the differential pressure, the k-factor and the height. Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level.


The values of the k-factor and the height can be changed via bus system.


### Wiring RS485 Modbus RTU





## **Dimensions**





Туре	Weight
22ADP-554	0.90 lb [0.41 kg]
22ADP-554L	0.95 lb [0.43 kg]

## **Further documentation**

- Modbus Interface description
- Installation instructions