

Potable water valve, 2-way, Internal thread

- For potable water applications
- DVGW certified
- ACS certified
- WRAS certified
- Air-bubble tight





5-year warranty



| Type overview | |
|---------------|----|
| Туре | DN |
| B2125PW-Q | 32 |

Technical data

| E: | ın | cti | 'n | nai | Ы | ata |
|------|----|-----|----|-----|---|-----|
| - FI | ЛI | | | 16 | | ala |

| Valve size [mm] | 1.25" [32] |
|-----------------------------|---|
| Potable water certificate | NSF/ANSI 61 |
| | NSF/ANSI 372 |
| Fluid | Potable water |
| Fluid temperature | -4.0212°F [-20100°C] |
| Close-off pressure ∆ps | 230 psi |
| Differential pressure Δpmax | 25psi |
| Leakage rate | 0% |
| Angle of rotation | 90° |
| Pipe connection | Internal thread |
| | NPT (female) |
| Installation orientation | upright to horizontal (in relation to the stem) |
| Servicing | maintenance-free |
| Cv | 82 |
| Valve body | Lead free and dezincification resistant bronze (CW511L) |
| Stem | Lead free and dezincification resistant bronze (CW511L) |
| Seat | PTFE |

Safety notes



Materials

0-ring

Ball

• The ball valve has to be exercised at least once a week, so that the quality of potable water as well as the functionality are not affected.

EPDM

Chrome plated lead free brass

- The valve has been designed for use in stationary potable water systems and must not be
 used outside the specified field of application, especially in aircraft or in any other airborne
 means of transport.
- The valve does not contain any parts that can be replaced or repaired by the user.



Product features

Operating mode

The on/off ball valve is adjusted by a rotary actuator. The rotary actuator is connected by an on/off signal. Open the ball valve counterclockwise and close it clockwise.


Installation notes

Notes

The ball valve is a regulating device. To fulfil this control task in the long term, the circuit must be kept free from particle debris (e.g. welding beads during installation work).

Permissible installation orientation

The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards.



Servicing


Ball valves and rotary actuators are maintenance-free.

Before any service work on the control element is carried out, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level).

The system must not be returned to service until the ball valve and the rotary actuator have been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel.


Flow direction

Please also ensure that the ball is in the correct position (marking on the shaft).




Dimensions

| Туре | DN | Weight |
|-----------|----|--------|
| B2125PW-Q | 32 | |





Dimensions





On/Off, Spring return, 24 V



| Technical data | | | |
|-----------------|-------------------------------------|--|--|
| Electrical data | Nominal voltage | AC/DC 24 V | |
| | Nominal voltage frequency | 50/60 Hz | |
| | Nominal voltage range | AC 19.228.8 V / DC 21.628.8 V | |
| | Power consumption in operation | 5 W | |
| | Power consumption in rest position | 2.5 W | |
| | Transformer sizing | 7.5 VA | |
| | Auxiliary switch | 2x SPDT, 1 mA3 A (0.5 A inductive), DC 5 VAC 250 V, 1x 10% / 1x 1190% | |
| | Switching capacity auxiliary switch | 1 mA3 A (0.5 A inductive), DC 5 VAC 250 V | |
| | Electrical Connection | (2) 18 GA appliance cables, 3 ft [1 m], with 1/2" NPT conduit connectors | |
| | Overload Protection | electronic throughout 095° rotation | |
| Functional data | Direction of motion motor | selectable by ccw/cw mounting | |
| | Direction of motion fail-safe | reversible with cw/ccw mounting | |
| | Manual override | 5 mm hex crank (3/16" Allen), supplied | |
| | Angle of rotation | 90° | |
| | Running Time (Motor) | 75 s / 90° | |
| | Running time fail-safe | <20 s @ 20°C | |
| | Noise level, motor | 45 dB(A) | |
| | Noise level, fail-safe | 62 dB(A) | |
| | Position indication | Mechanical | |
| Safety data | Power source UL | Class 2 Supply | |
| | Degree of protection IEC/EN | IP54 | |
| | Degree of protection NEMA/UL | NEMA 2 | |
| | Enclosure | UL Enclosure Type 2 | |
| | Agency Listing | cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02 CE acc. to 2014/30/EU and 2014/35/EU | |
| | Quality Standard | ISO 9001 | |
| | UL 2043 Compliant | Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC | |
| | Ambient humidity | Max. 95% RH, non-condensing | |
| | Ambient temperature | -22122°F [-3050°C] | |
| | Storage temperature | -40176°F [-4080°C] | |
| | Servicing | maintenance-free | |
| Weight | Weight | 5.2 lb [2.4 kg] | |



Technical data

Materials Housing material Galvanized steel and plastic housing

Footnotes †Rated Impulse Voltage 800V, Type of action 1.AA, Control Pollution Degree 3

Electrical installation

X INSTALLATION NOTES

(A) Actuators with appliance cables are numbered.

Provide overload protection and disconnect as required.

Two built-in auxiliary switches (2x SPDT), for end position indication, interlock control, fan startup, etc.

Actuators may be powered in parallel. Power consumption must be observed.

A Parallel wiring required for piggy-back applications.

Apply only AC line voltage or only UL-Class 2 voltage to the terminals of auxiliary switches. Mixed or combined operation of line voltage/safety extra low voltage is not allowed.

Meets cULus requirements without the need of an electrical ground connection.

Warning! Live electrical components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

Wiring diagrams On/Off

