

H800

Solid-Core Current Switch, Fixed Trip Point

1. The current sensor shall induce power from the monitored load.
2. The current sensor shall provide on/off status indication of electrical loads from 0.25 to 200 A.
3. The current sensor shall have an auto adjusting operating range from 0.25 to 200 A.
4. The current sensor trip point shall be fixed at 0.25 A or below.
5. The current sensor shall be capable of providing accurate status at temperatures from -15° to 60°C.
6. The current sensor shall be isolated to 600 VAC RMS.
7. The current sensor output shall be N.O., solid state, 1.0 A @ 30 VAC/DC
8. The current sensor shall be a solid-core type with a center window size of 0.71" diameter.
9. The current sensor dimensions shall be (LxWxH) 2.77" x 1.80" x 1.02".
10. The current sensor shall have a mounting bracket with adjustable positioning.
11. The current sensor shall be a Hawkeye model H800.